



0130TS/3

Assembly of Ceramic Fountain.

1. Contents include: Ceramic bowl, ceramic pedestal, ceramic fountain vase, and pump mechanism. (Pump has its own set of manufacturer's instructions and safety warnings which should be followed.)
2. Unpack contents. Place ceramic bowl on even surface.
3. Place pump mechanism inside ceramic bowl.
4. Pull electric plug outside of bowl. DO NOT PLUG IN and shield from getting it wet.
5. Place ceramic pedestal over pump using side opening in pedestal to run electric plug cord through.
6. Ceramic fountain vase comes with clear water tubing already attached to top fountain bowl opening and running through the inside of vase to bottom hole in fountain base. Reach inside bottom hole of fountain vase and GENTLY pull extra tubing out of bottom. CAREFUL: DO NOT TO PULL TOO HARD AND DISLODGE CONNECTION IN TOP.
7. Have two people hold fountain vase over ceramic pedestal. Have 3rd person connect clear water tubing from fountain vase to top nozzle on pump mechanism.
8. Place fountain vase on ceramic pedestal.
9. Fill bowl with enough water to make sure pump is completely submerged but not over the top of pedestal.
10. Plug in pump. Add water occasionally to compensate for evaporation.